

Fluxgate	Pypilot	Implied Adjustment
5	73	-68
8	66	-58
10	70	-60
11	77	-66
15	80	-65
22	82	-60
23	84	-61
31	91	-60
36	90	-54
44	99	-55
47	98	-51
48	96	-48
50	102	-52
58	105	-47
61	109	-48
63	108	-45
84	120	-36
87	121	-34
87	123	-36
93	124	-31
98	127	-29
103	129	-26
112	133	-21
282	221	61
312	238	74
320	255	65
322	254	68
339	310	29
345	354	-9
350	11	-21
352	24	-32